

SunfX

Sunless Tanning

Pro Mini V2
Professional Mobile Tanning System



SunFX Pro Mini V2

Hello gorgeous and welcome to the SunFX family. Thank you for trusting us to provide you with the perfect tan that leaves you glowing and radiant. We take pride in knowing that the product you are putting on your beautiful skin is only the best and most natural ingredients while also being applied only with the highest quality machine. We want your skin to be left happy all year round. No matter the occasion, SunFX is here to insure every skin tone is taken care of with one of our award winning solutions.

The Pro Mini V2 is the latest in lightweight and portable spray tanning machines brought to you by SunFX America.

Our V2 has been created to be the most versatile machine in the industry. It has been carefully designed for salons, on the go technicians and at home operators. Our Pro Mini V2 has been specially manufactured to fit our SunFX solution that will ensure every spray tan provided looks natural and even.

Please visit us at sunfxamerica.com to become a certified professional spray tan technician.

Thank you,

The SunFX family

Field of Application

The SunFX Pro Mini V2 spray tanning system has been specifically designed for the application of Professional SunFX liquid spray tanning solutions. Any application that is not SunFX branded solutions is not permitted and will immediately void ALL warranty of our V2 system.

Important safety instructions



WARNING

SAVE THESE INSTRUCTIONS

To reduce the risk of fire or explosion, electrical shock and the injury to persons, read and understand all instructions included in the manual. Be familiar with the controls and proper usage of the equipment.


- Risk of fire or explosion! Solvent and paint fumes can explode or ignite, causing severe injury and property damage.
- Paints and solvents containing halogenated hydrocarbons can react explosively with aluminum. Always check the product's label before using these materials in the unit.
- Hazardous vapors: Paint, solvents, insecticides, and other materials may be harmful if inhaled, causing severe nausea, fainting or poisoning.
- Make sure the room is well ventilated. Avoid all ignition sources, such as static electricity sparks, open flames, hot objects, sparks from connecting and disconnecting power cords, and working light switches.
- Follow the material and solvent manufacturers safety precautions and warnings. Do not use liquids with flash points less than 100 degrees Fahrenheit (38 degrees Celsius).
- Static electricity can be produced by HVLP spraying. Make sure any electricity conductive object being sprayed is grounded to prevent static sparking. The sprayer is grounded to prevent static sparking. The V2 is grounded through the electrical cord on the unit. If an extension cord is necessary, that extension cord must be a grounded three-pronged cord. One that is made for the appropriate voltage used.
- Keep the turbine at the maximum distance from the spraying area.
- The V2 is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision and instruction.
- Children should be supervised and instructed not to play with the Pro Mini V2.

Model Details


THE PRO MINI V2 IS PACKED WITH:

- 1x Turbine with Power Cord
- 1x Quick release Air Hose
- 1x V2 Spray Tan Applicator
- 1x User Manual

PRO MINI V2 TURBINE



PRO MINI V2 SPRAY APPLICATOR



GETTING STARTED

HOSE CONNECTION

Locate the male end of the air hose and connect it to the female quick connect on the V2 spray tan system.

To insert the coupler, pull back on the ring of the black coupler located on the V2 system and connect it to the male connector on the hose.

Release the ring to allow the coupler to snap into place. The hose should now be connected to the unit.



PREPARE THE SPRAY APPLICATOR

1- Unscrew the plastic cup from the applicator. Pour SunFX sunless tanning solution into the cup. Do not fill more than 3/4 full.









CAUTION Carefully screw the cup back onto the main body of the Spray Gun. Screw the cup on firmly but DO NOT over tighten. Over tightening will cause the cup to “pop” and damage the threads. Leakage will require replacement of the cup.

2- Locate the chrome spray nozzle. Slightly loosen the nozzle ring by turning counterclockwise. You can now rotate the spray nozzle freely.



3- Look at the spray applicator patten diagram below. Position 1 is for spraying up and down, position 2 is for spraying side to side, position 3 will spray a circle. Positions 1 and 2 are the most common for applying SunFX spray tan solutions.

Spray Nozzle	Spray Pattern	Use/Purpose
		Spray up & down preferred position
		Spray across from side to side
		Spray in small circle (contouring)

4- Turn the spray nozzle to the desired position and tighten the nozzle ring clockwise to lock firmly into place.



SET UP STEPS

1- Position your Mini Pro V2 unit as far away as practical from the area where you will be spraying. We suggest around the side of your SunFX pop up tent.

2- Finish attaching your spray applicator to the other end of the hose (see image below) by pulling back on the collar of the black connector on the air hose, push the connector over the coupler on the spray applicator and release. Your spray applicator should now be firmly attached to the air hose.



3- Plug your SunFX Pro Mini V2 spray tan system into an approved 120V USA/CAN or 240V EU/AUS/NZ electrical outlet. You will find your voltage on the underside of your turbine. Do not attempt to connect the unit to the incorrect electric current, as this will not only damage your unit and void your warranty.



4- Turn the unit on and start spraying. The unit is pre-set at optimal speed, therefore no extra controls are required.


YOUR SYSTEM IS NOW READY TO USE!

HOW TO BEST USE YOUR PRO MINI V2

ADJUSTING THE SPRAY APPLICATOR

- The solution flow screw is located on the back of the handle below the hose coupling.
- Turning the flow screw clockwise reduces the SunFX solution flow.
- Turning the flow screw counterclockwise will increase the flow of SunFX solution .
- If the flow screw has been completely turned clockwise to a closed position, you will find turning 1-2 full turns counter-clockwise will provide a good flow of SunFX solution. If more or less flow is required, turn the dial accordingly.



 **CAUTION** DO NOT over tighten the screw as this will cause damage to the end of the spray needle.

USING THE SPRAY APPLICATOR

- The spray applicator allows solution to be emitted when the trigger has been pressed. Successful spraying will be achieved when the operator can move the applicator while pressing the trigger in an on and off again motion. Never hold the trigger on continually. This will cause excessive over spray on the client and tent area and can lead to a costly waste of solution.
- The SunFX applicator is designed to be held 6" (15 cm) from the person being sprayed. This will provide the best coverage and minimize solution overspray and wastage.
- Move your hand at a slow, steady pace keeping the distance of the spray applicator the same throughout the application. This will ensure sufficient product on all parts of the body.
- You will know you have the correct flow of solution if the result on the skin resembles an airbrushed finish. If the solution beads on the skin, your flow of product is too high and you will need to dial down the solution flow.
- For best practice hold your spray applicator in a vertical position when spraying. If you wish to change the direction of the mist pattern, rotate the position of the spray nozzle, rather than turning the spray applicator on its side.
- Always hold or store your applicator in a vertical position. Utilize the storage compartment located on the top of your Pro Mini V2 system.

TRAINING CERTIFICATION PROGRAM

If you would like to take our online SunFX certification program please visit www.sunfxamerica.com or reach out to info@sunfxamerica.com

TROUBLE SHOOTING

Problem	Cause	What to do
The Spray Unit will not turn on	Power cord not attached	Ensure that the power cord is pushed in firmly to the base of the unit and wall socket
	Electricity not turned on	Ensure the power point is on
	The unit is not turned on	Press the On/Off Button at the back of the unit.
The spray applicator is leaking	Spray Cup is not tight enough	Tighten the solution cup
	Solution cup seal missing	Insert the rubber cup seal
	Too much solution	Empty some solution from the spray cup
	Nozzle may be blocked	Spray warm water through the applicator
The spray is spluttering No solution is coming out of the spray applicator	Solution cup low	Add solution to the cup
	Air speed is too low	Check the filter for blockages
	Angled applicator too sharply while spraying	Keep the applicator on a lesser angle while spraying
	Nozzle may be blocked	Spray warm water through the applicator
	Filter could be blocked	Ensure the filter underneath the Spray Unit is clean
	Spray applicator control dial is set too low	Wind in solution knob below the hose connector of the gun
	Nozzle may be blocked	Spray warm water through the applicator
	Solution cup low	Add solution to the cup
	Trigger is jamming	Spray warm water through the applicator repeatedly ensuring the Solution Dial is allowing maximum water through the applicator
	Solution Dial on applicator set too low	Increase solution dial on applicator, number 1 being the lowest and Number 8 being the highest setting
The applicator is continuing to spray	Trigger or nozzle is jamming	Spray warm water through the applicator repeatedly ensuring the Solution Dial is allowing maximum water through the applicator
Hose coming out of unit	Hose not correctly fitted to unit	Ensure the fitting is inserted and quick connect fitting is locked into place.
	Hose fitting broken from over tightening	Contact your supplier or service agent

TIPS AND TRICKS

Problem	Cause	What to do
The solution is sitting on the skin or beading on the client	Too much tanning solution has been sprayed onto the skin	Dab area gently with a clean dry towel and re-spray lightly, blending the tan in
	Client has not prepared their skin correctly i.e. moisturiser or perfume on the skin	
	Client maybe excessively hot and perspiring	
The client has tanning solution in areas they don't wish to tan	The technician has sprayed the area incorrectly	Exfoliate the area using tan removing product for best results or a cloth and soap
	Client has touched part of their body with a spray tanned area	
The client appears orange	Too much tanning solution has been sprayed onto the skin	Exfoliate the skin before re-spraying and ensure the spray application is lighter
	The client may have left a rapid tanning solution on too long	
	The client may have low toleranceto DHA	
The spray tan has not developed as dark as desired	The spray tan solution used may be old or heat affected reducing the reaction in the skin. Sometimes a green hue will appear to indicate this	<p>Be sure to keep the solution in a cool dry place and ensure the solution is fresh.</p> <p>Ensure the client has followed the correct recommendations for preparation and post spray tan care.</p> <p>The client can be resprayed if required after their minimum 8 hours and after a shower has been taken</p>
	A different solution was sprayed or the spray application dial was set lighter	
	The client may have showered or perspired before the tan could develop	
	Other factors may affect the tan's development, including diet, hormones and medication. Please refer to the client	

SunFX Customer Service Hotline: +1 858 684 3010

info@sunfxamerica.com

www.sunfxamerica.com

WARRANTY INFORMATION

IMPORTANT Please keep your proof of Purchase and User Manual in a safe place as you will require these to make a warranty claim. Prior to making a claim you should read through the trouble shooting section in the manual and contact SunFX America or your supplier. Any warranty claims should be made directly to SunFX America or your supplier.

If within one (1) year from the date of purchase, the product fails due to a defect in material or workmanship, we will repair if possible or replace it free of charge with a comparable unit which may be new or refurbished. This warranty applies only to the original purchaser and is not transferable. The goods must be returned to the seller with proof of purchase to be assessed at the purchasers cost.

Warranties shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care. The manufacturer shall not be obligated under these warranties:

- a) to repair damage resulting from attempts by personnel other than authorized representatives to install, repair or service the product.
- b) to repair damage, malfunction, or degradation of performance resulting from improper use or incompatible solution.
- c) to perform maintenance or cleaning or to repair damage, malfunction, or degradation of performance resulting from failure to perform user maintenance and cleaning as prescribed.
- d) to repair damage, malfunction, or degradation of performance resulting from use of the product in an environment not meeting the operating specifications.

To activate your warranty, please complete the information below and email or mail to your supplier within 14 days of purchase.



WARRANTY CARD



Model Type:	<input type="text"/>	Serial Number:	<input type="text"/>
Supplier Name:	<input type="text"/>	Date Of Purchase:	<input type="text"/>
Name:	<input type="text"/>		
Address:	<input type="text"/>	Suburb:	<input type="text"/>
Post Code:	<input type="text"/>	State:	<input type="text"/>
		Country:	<input type="text"/>
Email:	<input type="text"/>	Phone:	<input type="text"/>
Business Type:	<input type="checkbox"/> Beauty	<input type="checkbox"/> Tanning	<input type="checkbox"/> Hair
	<input type="checkbox"/> Mobile	<input type="checkbox"/> Home	

MAINTENANCE GUIDE

SPRAY APPLICATOR

Note: It is important to clean your spray applicator at the end of each spray day. Failure to do so, will result in blockages over time, NOT covered by warranty.

Step 1 Remove hose and wipe with a damp cloth.

Step 2 Unscrew solution cup and empty any excess solution. It is recommended that this be done over a sink or a wet area.

Step 3 Rinse the empty solution cup with warm water.

Step 4 With warm water in the solution cup, spray the water through the applicator. Use the highest setting for maximum water spraying when cleaning.

Step 5 Empty solution cup and re-set the solution dial on the back of the gun to the regular spray setting.

Step 6 Wipe any excess water from the applicator with a cloth and warm water.

Step 7 Store applicator with out the solution cup attached.

SPRAY TURBINE

Step 1 Clean the Spray Turbine with a cloth. Avoid using anything abrasive.

Step 2 Clean the filter. Remove the filter from the base of the unit and rinse in warm water. Wait until filter is completely dry before re-fitting. Positioning the spray turbine as far away as practical from the spray technician when in use will ensure the unit stays cleaner for longer.

